Disclaimer

- The material provided in this document is not my original work and is a summary of some one else's work(s).
- A simple Google search of the title of the document will direct you to the original source of the material.
- I do not guarantee the accuracy, completeness, timeliness, validity, non-omission, merchantability or fitness of the contents of this document for any particular purpose.
- Downloaded from najeebkhan.github.io

Chapter # 6: Transcriptions and Label Files


HMM TOOL KIT HTK

Outline

- Introduction
- Label File Structure
- Label File Formats
- Master Label Files
- Editing Label Files

Introduction

- Many of the operations performed by HTK which involve speech data files assume that the speech is divided into segments and each segment has a name or label
- When very large numbers of files are being processing, label file access can be greatly facilitated by using Master Label Files (MLFs)



- Most transcriptions are single-alternative and single-level, that is to say, the associated speech file is described by a single sequence of labelled segments
- In training a HMM system it is useful to have both the word level transcriptions and the phone level transcriptions side-by-side
- All non-HTK formats are limited to singlelevel single-alternative transcriptions

ice	cream
-----	-------



(a) 1-alternative, 1-level

ice		cream			
ay	S	k	r	iy	m



(b) 1-alternative, 2-level

I	scream					
ice	cream					
eyes	cream					



(c) 3-alternative, 1-level

 As with speech data files, HTK not only defines its own format for label files but also supports a number of external formats other than HTK (SOURCELABEL, TARGETLABEL)

HTK Label Files

- The HTK label format is text based
- A single label file can contain multiple alternatives and multiple-levels

```
[start [end]] name [score] { auxname [auxscore] } [comment]
```

HTK Label Files

0000000 36000 3600000 82000			REFER	2200000	Service Control
			///	8200000	scream
0000000 22000	00 ay	ice	0000000	3600000	ice
2200000 36000	00 s		3600000	8200000	cream
3600000 43000	00 k	cream	///		
4300000 50000	00 r		0000000	3600000	eyes
5000000 74000	00 iy		3600000	8200000	cream
7400000 82000	00 m				

- ESPS Label Files
 - An ESPS/waves+ label file is a text file with one label stored per line
 - Each label indicates a segment boundary

```
time ccode name
```

- TIMIT Label Files
 - TIMIT label files are identical to single-alternative single-level HTK label files without scores
 - Start and end times are given as sample numbers rather than absolute times

- SCRIBE Label Files
 - The HTK SCRIBE format recognizes just three label types

LBA — acoustic label LBB — broad class label UTS — utterance

- The LBA and LBB types have 4 fields: start sample, center sample, end sample and label
- The UTS type has 3 fields: start sample, end sample and label
- For use in HTK word blanks are converted to underscore characters

- To use a training tool with isolated word data may require the generation of hundreds or thousands of label files each having just one label entry
- Each label file must be stored in the same directory as the data file it transcribes, or all label files must be stored in the same directory
- Every HTK tool which uses label files has a -I option which can be used to specify the name of an MLF file

- MLFs can do two things
 - They can contain embedded label definitions so that many or all of the needed label definitions can be stored in the same file
 - They can contain the names of sub-directories to search for label files

```
MLF =
               "#!MLF!#"
               MLFDef { MLFDef }
 MLFDef =
              ImmediateTranscription | SubDirDef
ImmediateTranscription =
              Pattern
              Transcription
SubDirDef = Pattern SearchMode String
SearchMode = "->" | "=>"
```

```
a.lab contains

000000 590000 sil
600000 2090000 a
2100000 4500000 sil
```

```
000000 990000 sil
1000000 3090000 b
3100000 4200000 sil
```


b.lab contains

```
#!MLF!#
"*/a.lab"
000000 590000 sil
600000 2090000 a
2100000 4500000 sil
.
"*/b.lab"
000000 990000 sil
1000000 3090000 b
3100000 4200000 sil
```

```
#!MLF!#
"*/one.*.lab"
one
"*/two.*.lab"
two
"*/three.*.lab"
three
<etc.>
```

```
#!MLF!#
"*" -> "/db/dr1/labs"
"*" -> "/db/dr2/labs"
...
"*" -> "/db/dr7/labs"
"*" -> "/db/dr8/labs"
```

```
#!MLF!#
"*/dr1_*" -> "/db/dr1/labs"
"*/dr2_*" -> "/db/dr2/labs"
...
"*/dr7_*" -> "/db/dr7/labs"
"*/dr8_*" -> "/db/dr8/labs"
```



- HTK training tools typically expect the labels used in transcription files to correspond directly to the names of the HMMs chosen to build an application
- Hence, the label files supplied with a speech database will often need modifying
- Groups of labels corresponding to a sequence of acoustic events (e.g. pcl p') might need converting to some simpler form (e.g. p) which is more suitable for being represented by a HMM
- The labels in the transcription must be converted to show the required contexts explicitly.

- HTK supplies a tool called HLEd for rapidly and efficiently converting label files
- The HLEd command invocation specifies the names of the files to be converted and the name of a script file holding the actual HLEd commands

HLEd -1 newlabs edfile.led 11 12 13

 Each edit command stored in an edit file is identified by a mnemonic consisting of two letters

```
# Map 61 Phone Timit Set -> 48 Phones

SO

DE q

RE cl pcl tcl kcl qcl

RE vcl bcl dcl gcl

RE sil h# #h pau

5478 5643 b

5643 6360 iy

6360 7269 tcl

7269 8313 t

8313 11400 ay

11400 12950 dcl
```

```
0 1400625 sil
                1400625 1696875 w
                1696875 2725000 ow
                2725000 3423750 vcl
                3423750 3526875 b
               3526875 3975000 iy
6360 7269 tcl 3975000 4543125 cl
               4543125 5195625 t
8313 11400 ay | 5195625 7125000 ay
11400 12950 dcl 7125000 8093750 vcl
12950 14360 dh | 8093750 8975000 dh
14360 14640 h# | 8975000 9150000 sil
```


ME b bcl b
ME d dcl dh
ME t tcl t

```
DC V iy ah ae eh ix ... CH V-ah+V V ah V
DC C t k d k g dh ... CH V-ah+C V ah C
DC L l r w j ... CH V-ah+N V ah N
DC N n m ng ... CH V-ah+L V ah L
DC S h# #h epi ... CH V-ah+L V ah L
etc
```

Recognition Output

```
"'*'/1to9.rec"
0 3600000 one -2852.590088
3600000 4500000 six -661.472961
4500000 5700000 silence -526.582642
5700000 8100000 two -1732.673218
8100000 9000000 six -661.718262
9000000 10600000 silence -823.747559
10600000 13700000 three -2177.576904
13700000 19100000 four -3675.707275
19100000 20000000 silence -535.357056
20000000 24800000 five -3246.559570
24800000 25700000 silence -460.714935
25700000 29900000 six -3184.442871
29900000 30800000 silence -488.392578
30800000 35200000 seven -3200.251709
35200000 37200000 silence -1066.845337
37200000 39700000 eight -1636.414307
39700000 42700000 silence -1624.928955
42700000 45500000 nine -2064.114014
45500000 46400000 six -656.805420
46400000 48000000 silence -805.105774
48000000 51300000 zero -2384.838867
51300000 52300000 six -708.313904
```

Recognition Output



ThankYou